


KF-Y2004 Assembly Manual









Dining Chair



▲ CAUTION


THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.

PLEASE READ AND KEEP FOR FUTURE REFERENCE.


<p>Ax1</p>  <p>Back</p>	<p>Bx1</p>  <p>Seat</p>
<p>Cx2</p>  <p>Front Leg</p>	<p>H1x5</p>  <p>Short Bolt (M8 x 65mm)</p>
<p>H2x4</p>  <p>Long Bolt (M8 x 85mm)</p>	<p>H3x9</p>  <p>Flat Washer</p>
<p>H4x9</p>  <p>Lock Washer</p>	<p>H5x1</p>  <p>Allen Key</p>

ASSEMBLY INSTRUCTIONS

- 1 Remove the hardware package and the front legs from the underneath pocket of the upholstered seat.




- 2 Attach seat (B) to back (A), using short bolt (H1), long bolt (H2), lock washers (H4), flat washers (H3), and allen wrench (H5).
Note: Two different sizes of bolts are required for this step.





- 3** Attach front legs (C) to seat (B), using short bolts (H1), lock washers (H4), flat washers (H3), and allen wrench (H5).

Note: Do not fully tighten yet.



- 4** Turn assembled chair upright and place on a flat surface. Push legs up or down as necessary to level. **Once level, tighten all bolts.**



5 Assembly complete. Enjoy.

