

# CHITA® Keaton Sofa Collection


Sofa & Arm Chair



# Specification

Each piece comes with one box.






# **CAUTION**

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

## **Arm Chair**

#### Front Legs (X2) Back Legs (X2)





Allen Key (X1)



Power tools are NOT recommended

Bolts (X2)

Flat Washers (X2)





Washers (X2)

Spring Washers (X2)











# **Assembly Instructions**

Components


Remove the legs and hardware pack from the zippered compartment at the bottom of the chair.



Attach the Front Legs to the chair, using Bolts, Flat Washers, Spring Washers and Allen Key. Fully tighten. Rotate the Back Legs into the chair firmly.



### Components



Front Legs (X2)



Sofa





Allen Key (x1)

Middle Leg (X1)



Power tools are NOT recommended



Bolts (X2)


Flat Washers (X2)







Washers (X3)




# **Assembly Instructions**







Remove the legs and hardware pack from the zippered compartment at the bottom of the sofa.



Attach the Front Legs to the sofa, using Bolts, Flat Washers, Spring Washers and Allen Key. Fully tighten. Rotate the Back Legs and Middle Leg into the sofa firmly.

