


# DC7Y050 Assembly Manual








## Swivel Dining Chair



**CS.furniture@outlook.com**

**▲ CAUTION**


THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.  
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

<p>A x 1</p>  <p>Chair Body</p>	<p>B x 1</p>  <p>Chair Base</p>	<p>C x 1</p>  <p>Swivel Plate</p>
<p>H1 x 8</p>  <p>M6X20mm</p>	<p>H2 x 8</p>  <p>Spring Washer</p>	<p>H3 x 8</p>  <p>Flat Washer</p>
<p>T1 x 1</p>  <p>Allen Wrench</p>		


Please read through the instructions below to familiarize yourself with the parts and steps before assembly.

## ASSEMBLY INSTRUCTIONS

- 1 Unpack and place the Swivel Plate(C) and hardware from the carton. Make sure all parts are present before assembly. Assemble on a soft and smooth surface to prevent damage to the product.




- 2 Rotate the swivel plate by 45 degree.





- 3** Attach the Swivel Plate (C) to the Chair Base (B) using Bolts (H1), Spring Washers (H2), and Flat Washers (H3).

Note: Do not fully tighten any bolts initially. After all four bolts are attached, use Allen Wrench (T1) to fully tighten them.




- 4** Attach the Chair Base (B) to the Chair Body (A) using Bolts (H1), Spring Washers (H2), and Flat Washers (H3). First, rotate the Chair Base (B) by 45 degrees and loosely attach the first bolt. Then sequentially turn by 45 degrees to attach the remaining bolts.

Note: Do not fully tighten any bolts initially. After all four bolts are attached, use Allen Wrench (T1) to fully tighten them.



- 5** Assembly complete. Take a spin and enjoy.



# Design Exquisite Furniture For Your Home

---

## PRODUCT WARRANTY

- 1-year limited on cover against splitting, peeling, and/or tearing.
- 1-year limited on internal and external frame structure.
- 1-year limited on cushioning material, seat springs and mechanism.

## Contact us:

We make all efforts to guarantee that the products you receive are in excellent condition. If there are any parts missing or damaged, the Customer Service Team will be happy to provide free replacements for you. We have professional warehouses where the current inventory of parts is enough so that they will arrive in your hands as fast as possible.

Assistance with assembly or product details is available; don't hesitate to get in touch with us to get priority service.

Our E-mail address: [CS.furniture@outlook.com](mailto:CS.furniture@outlook.com).



**[CS.furniture@outlook.com](mailto:CS.furniture@outlook.com)**