


Assembly Manual BS7025

BS7025 Assembly Manual Bar Chair





THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

СНІТЛ

A x 1	B x 1 Right Arm	C x 1 Backrest	D x 1
Ex1	F x 1	G x 1	H x 1
Seat Cushion	Front Rail	Front Bottom Rail	Back Bottom Rail
H1 x 8	H2 x 4	H3 x 2	H4 x 1
			Ĺ
Short Bolts M6 x 50mm	Lock Washers 5/16"	Flat Washers 1/4" x 19mm	Allen Wrench M4 x 100mm
H5 x 2 (ᢧ)_ႍၮၮ≫	H6 x 4	H7 x 2	H8 x 4
Deep Head CSK Screw M5 x 25mm	CSK Screw M4 x 38mm	Wood Dowel M8 x 30mm	Wooden Plugs
Extra Hardware ())))))))) ()) ()) ()) ()) ())	Not Included		

Before you begin:

1. Check if you have received all parts using the diagram on this page. Do not start the assembly process until all parts are present. If you have not received all parts or received wrong or damaged ones, please contact our customer service and we will get back to you.


2. Do not discard any of the packaging until you are certain that you have all the necessary parts for the assembly.

3. Do NOT use power tools for assembly.




2

Attach the Front Rail (F) to the Left Arm (A), using Lock Washers (H2), Short Bolts (H1) and Allen Wrench (H4). **Do not fully tighten yet.**



Assemble the Backrest (C) using Lock Washers (H2), Short Bolts (H1) and Allen Wrench (H4). **Do not fully tighten yet.**






3 Insert the Front Bottom Rail (G) and Back Bottom Rail (H) to the Left Arm (A).


Note : Do not install any screws yet.

А






Insert the Right Arm (B) to the assembled frame in Step 3.






5 Assemble the Right Arm (B) in Step 4, using Locker Washers (H2), Short Bolts (H1) and Allen Wrench (H4). **Do not fully tighten yet.**



Insert the Wood Dowel (H7) to the Front Rail and Backrest.

X 2 H7

6






8


Assembly Manual BS7025

Attach the Seat Cushion (E).


Note: Please pay attention to the Front Sticker.




Move on to the holes from Seat Cushion (E). Assemble the Front Rail (F) with Seat Cushion (E), using Short Bolts (H1) and Allen Wrench (H4). Assemble the Backrest (C) with Seat Cushion (E), using Flat Washers (H3), Short Bolts (H1) and Allen Wrench (H4). **Do not fully tighten yet.**











Push the Left Arm and Right Arm inward, and tighten with Deep Head CSK Screw (H5) and Allen Wrench (H4). **Do not fully tighten yet.**




СНІТЛ

Turn assembled chair upright and place on a flat surface. Push legs up or down as necessary to level.
Once level, tighten all helts and service.

Once level, tighten all bolts and screws.



Gently tap the Wooden Plugs (H8) into Left Arm and Right Arm. Put on the Back Cushion (D). Assembly complete.






13

Assembly complete.

Note: Each leg has an adjustable foot leveler to help level the chair.



СНІТЛ

PRODUCT WARRANTY

- . 1-year limited on cover against splitting, peeling, and/or tearing.
- . 1-year limited on internal and external frame structure.
- . 1-year limited on cushioning material, seat springs and mechanism.

CARE & MAINTENANCE

Water Based Cleaner 'W' Spot clean using the foam only from a waterbased cleaning agent such as a mild detergent or non-solvent upholstery shampoo product. Apply foam with a soft in circular motion. Vaccum when dry.

Do not place furniture in direct sunlight and keep furniture at least 60 cm / 2 feet from heat sources to avoid fading.



If at any step you need a helping hand, we're always here for you. You can

email us, or hop into a live chat on our website - whatever method is convenient

for you.



support@chitaliving.com